

## Installation guide: Austroflex Foot and Side Stopper

Foot Stopper Installation











Side Stopper Installation







Foot stoppers: Install I per side along foot of bed.

2 total for Queen and King sizes, I total for Full and Twin sizes.

Side stoppers: Install 2 per side - 4 total for Twin,

Full, Queen, and King sizes.